


salva piatti



10120



10121



10145



CUCINA

Cod.	Descriz./Descrip.	Dim. cm	Colore/Color	Pack.	Ean
10120	salva piatti piccolo	30 x 30	bianco/white	CT 50	800763310120 5
10107	salva piatti piccolo	30 x 30	giallo/yellow	CT 50	800763310107 6
10109	salva piatti piccolo	30 x 30	argento/silver	CT 50	800763310109 0
10106	salva piatti piccolo	30 x 30	salvia/sage	CT 50	800763310106 9
10121	salva piatti grande	30 x 39	bianco/white	CT 50	800763310121 2
10110	salva piatti grande	30 x 39	giallo/yellow	CT 50	800763310110 6
10113	salva piatti grande	30 x 39	argento/silver	CT 50	800763310113 7
10111	salva piatti grande	30 x 39	salvia/sage	CT 50	800763310111 3
10145	salva piatti Set 3 PZ	2 x (30x30) + 30x39	bianco/white	CT 20	800763310145 8
10146	salva piatti Set 3 PZ	2 x (30x30) + 30x39	giallo/yellow	CT 20	800763310146 5
10147	salva piatti Set 3 PZ	2 x (30x30) + 30x39	argento/silver	CT 20	800763310147 2
10149	salva piatti Set 3 PZ	2 x (30x30) + 30x39	salvia/sage	CT 20	800763310149 6